

STEP 1: CONNECT PROBE TO CABLE REEL

- UNPACK ALL ITEMS FROM TRANSPORT CASE
- ENSURE THE CABLE REEL PROBE CONNECTOR IS LIGHTLY GREASED
- PUSH CABLE REEL PROBE CONNECTOR THROUGH PROBE HOLDER
- PUSH CABLE REEL PROBE CONNECTOR ONTO PROBE CONNECTOR
- SECURE IN PLACE WITH RED LOCKING COLLAR



- SLIDE PROBE INTO PROTECTIVE HOLDER:
- ALIGN PROBE FLATS WITH HOLDER FLATS
- GENTLY SLIDE BACKWARDS INTO HOLDER
- LOCK PROBE IN PLACE USING LOCKING BOLT



STEP 2: CONNECTING TOPSIDE BOX

- CONNECT MATING END OF CABLE REEL TO 'SENSOR' PORT
- CONNECT USB CABLE TO 'USB' PORT
- CONNECT OTHER END TO PC
- CONNECT POWER CABLE TO 'PWR' PORT



STEP 3: INSTALLING 'SEAVIEW'

- PLUG THE 'IMPACT SUBSEA' SUPPLIED USB INTO COMPUTER
- INSTALL 'SEAVIEW' ONTO PC
- RUN 'SEAVIEW'
- SEAVIEW WILL AUTO-DETECT PROBE
- CLICK ON FMD APP

FOR HELP WITH USING THE FMD APP PLEASE REFER TO THE MANUAL & VIDEO GUIDES THAT ARE AVAILABLE ON THE USB PROVIDED AS WELL AS THE IMPACT SUBSEA WEBSITE